






Guide at a glance to central heating controls

TYPE OF CONTROL	LOCATION AND FUNCTION
<div data-bbox="190 408 622 459" style="border: 1px solid black; padding: 2px; display: inline-block;">BOILER THERMOSTAT</div> 	<p>Found on the boiler itself. It controls the temperature of the water flowing around the pipes to the radiators. It also stops the boiler overheating. It is set on high in the winter and low in the summer.</p>
<div data-bbox="190 579 622 630" style="border: 1px solid black; padding: 2px; display: inline-block;">ROOM THERMOSTAT</div> 	<p>Usually found in the hallway. This controls the temperature of the whole house based on the temperature of the room it is in. It automatically switches the heating off once temperature has been reached and on again when temperature drops below that set.</p>
<div data-bbox="190 727 622 778" style="border: 1px solid black; padding: 2px; display: inline-block;">CYLINDER THERMOSTAT</div> 	<p>Hot water cylinder thermostat – this is found on the cylinder itself. It controls the temperature of the hot water coming out of the taps. The ideal setting is 60°C</p>
<div data-bbox="190 876 622 927" style="border: 1px solid black; padding: 2px; display: inline-block;">PROGRAMMER</div> 	<p>This is the most useful as it automatically switches on the heating and hot water at the set times</p>
<div data-bbox="190 1019 862 1070" style="border: 1px solid black; padding: 2px; display: inline-block;">THERMOSTATIC RADIATOR VALVES (TRV's)</div> 	<p>Thermostatic Radiator Valves (TRV's) – these are found on the radiator and allows you to control the temperature in each room</p>

To find out more contact:

New Forest District Council
Southampton Energy Efficiency Centre

023 8028 5607
0800 512012